


Cloud Platform User Manual



STEP 1

- 1. Register a new account
- 1.1 Visit the website of the Cloud platform at http://47.88.54.22:8090. Click Register to set up a new account.



1.2 Fill in the necessary information to finish the account registration.




1.3 An confirmation e-mail will be sent to the register after presenting the information. Login the mailbox to activate the new account. Go back to the Cloud platform website and login with the new account.

STEP 2


2. Status of the user and device

Click the Stats to check the statistic of the connecting terminals, MAC, AP devices, etc.




STEP 3

- 3. Add a new AP device. Make sure the AP is connecting to the Internet in order to synchronize the data and setting with the Cloud platform.
- 3.1 Click the Device to check the operating status of the AP which is linked to the Cloud platform.



3.2 Click the Device → Add, fill in the SN code, AP name, address and the Group information.



Remark: The SN code is in the product sticker. Or login the default IP address of the AP with 192.168.2.1. The SN code is showed in the system status. (The default account and the password is "admin")



STEP 4


4. AP Configuration

After the AP is added to the Cloud platform and it's online, the AP can be configured in the Ad authentication, SSID, encryption, transmitting power, etc.

4. 1 Set the single AP


This method is suitable for setting different SSID among different APs. It's recommended to set groups for easier management (refer to the STEP 6).


Click the Device → Device → Manage → Config




Click the Config and make settings on below pages. The new setting will take effect in several minutes after the confirmation from the Cloud platform.

- *Basic: set to use the AP template, the Ad Authentication, the schedule to reboot the AP
- *SSID: set the WiFi SSID, add multiple SSID and set passwords, choose the VLAN value
- *Frequency: set the wireless frequency and transmitting power
- *Black White List: set the black and while list of the domains
- *Advanced: WiFi probe setting and the WiFi connection parameters









Remark:


- 1. In the Basic page, when the Auth is enabled, Ad will be showed when connecting the WiFi.
- 2. In the Advanced page, when the QoS is enabled, the function of traffic control will be available.
- 3. In the Advanced page, when the WiFi Probe is enabled, the terminal with week connection signal will be forced to be offline from the WiFi.
- 4. In the Advanced page, the Status Interval decides how often the AP will report its working status. The value is between 1-120.
- 5. In the Advanced page, the Duration decides how often the Cloud platform will check if the terminal is online or not. The value is between 5-60.
- 4.2 Template Modification (Suitable to modify the AP setting in batch)
- 4.2.1 Click the Device and then the Template, click Add button to add a new template.



4.2.2 Fill the name of the template and choose the right AP model. Please note that the specific template is only available to the corresponding product model. The setting options in the template is the same to the single AP setting.



4.2.3 After finishing the template setting, apply the template in the designated APs. Click the Template, choose the template and click the Apply, choose the corresponding AP and confirm. The newly settings will be updated in the Cloud platform and will be available in a few minutes.





STEP 5

5. Configuration of the Auth Function

When the Auth is enabled, the terminals will receive a pop-up WiFi connecting page. If no connecting paged is preferred, the function can be disabled in the AP setting according to the Step 4.

5.1 Click Auth \rightarrow Ad-Manage \rightarrow Add, fill in the name of the Auth, choose the classic mode, and then choose the designated group to apply this function. Save the setting.







5.2 Click the Decorate of the new Ad in the list




- 5.3 Choose the Related Page for Decoration
- 5.3.1 The main page. The main page is the first page that the browser pops up when the terminal is connected to the WIFI. Click the Edit button in each module to modify the content of the authentication page.



5.3.2 Auth page. The Auth page is after the main page. One-key authentication can be selected in this page. Click Auth \rightarrow Edit, select the authentication method, fill in the intended Internal link, apply the settings.




5.3.3 Success page. The final page of showing advertisement during the authentication process. Advertising picture, display duration, redirect URL, etc can be set in this page. Apply settings afterwards.




5.3.4 Activate the advertisement.

After finishing the setting of all the three pages above, click Save on the top of the right side, and then click Push to activate the advertisement. Wait for three minutes and test the function with terminal devices. If failed to activate the Ad, please click Auth \rightarrow Ad-Manage \rightarrow Push. Click Add and fill in necessary info to activate the Ad in different groups.




There is a list showing all the information of the Ads and the corresponding activated group.




Page 10 of 13

5.3.5 Set the authentication expiration for different groups.

Click Auth \rightarrow Authentication Expiration \rightarrow Add. Set the value of authentication expiration based on hours. And set the value of duration of single WiFi connection based on hours.






STEP 6


6. Group management

Through the group management, user can manage multiple APs in different area and choose different authentications. For example, if there are two projects in different areas, Shopping Mall A and Shopping Mall B. Both of the projects needs the AP installation and different authentication pages. In this case, user can create group for each of the project and set the AP and corresponding authentication into the designated group.


6.1 Click System → Group → Add, create a new group Shopping Mall A (The default account owns the highest authority group, any new established groups belongs to the highest authority group)



6.2 Set the specific AP in the corresponding group. Click the Device \rightarrow Device \rightarrow Add, click the Edit of the corresponding AP and set it in the designated group.



6.3 Set the Ad authentication. Click the Auth \rightarrow Ad-Manage \rightarrow Ad tab, choose the right Ad and click the Edit to apply the Ad in the specify group.



6.4 On the top of the tab, it shows the relationship of the groups. Click in to check the Ad content in different groups.

